



This is an upright fin, so remember to put it back in the box about two inches when comparing to typical swept-back fins. This procedure lines up the centers of lateral resistance, so you can compare this fin accurately. If in doubt, slide the Wavegrinder back even more.

